COMMUNICATIONS RESOURCE AVAILABILITY WORKSHEET

Frequency Band: UHF/VHF/800

Description: Marysville ACS (WA7COM) 3.6.26

Pg No	Channel Configuration	Channel Name/Trunked Radio System Talkgroup	Eligible Users	RX Freq N or W	RX Tone/NAC	TX Freq N or W	Tx Tone/NAC	Mode A, D or M	Remarks
	Repeater	EOC-R1	City Staff	158.7750 N	156.7	153.8750 N	156.7	A	Msvl EM Primary Repeater
	Simplex	EOC-S1	City Staff	155.7900 N	156.7	155.7900 N	156.7	A	Msvl EM Simplex
	Repeater	EOC-MR	City Staff	151.9550 N	156.7	159.6750 N	156.7	A	Msvl EM Mobile Repeater
	Repeater	PW-RPT	City Staff	153.1700 N	127.3	160.1550 N	127.3	A	Msvl Public Works Repeater
	Repeater	MSVL1	Amateur	147.3800 N	156.7	147.9800 N	156.7	A	Msvl ACS Primary Repeater
	Simplex	MSVL1D	Amateur	147.3800 N	156.7	147.3800 N	156.7	A	Msvl ACS Repeater Talk-Around
	Simplex	MSVLSX	Amateur	147.5875 N	156.7	147.5875 N	156.7	A	Msvl ACS Primary Simplex
	Repeater	MSVL4	Amateur	442.7000 N	156.7	447.7000 N	156.7	A	Msvl ACS Alternate Repeater
	Repeater	UTAC41	Tactical	453.4625 N	156.7	458.4625 N	156.7	A	Portable UHF Interop Repeater
	Simplex	TAC41D	Tactical	453.4625 N	156.7	453.4625 N	156.7	A	UHF Interop Simplex
	Simplex	VTAC11	Tactical	151.1375 N	156.7	151.1375 N	156.7	A	VHF Interop Simplex
	Simplex	DEMSIM	SnoCo DEM	154.0550 N	127.3	154.0550 N	127.3	A	SnoCo DEM Simplex
	Repeater	DEMOSO	SnoCo DEM	154.0550 N	127.3	158.8500 N	103.5	A	SnoCo DEM Oso Repeater
	Simplex	SNOSX1	Amateur	144.4600 W	123.0	144.4600 W	123.0	A	SnoCo ACS Simplex
	Repeater	GRANIT	Amateur	146.9250 N	156.7	146.3250 N	156.7	A	SnoCo ACS Primary Repeater
	Repeater	FIRET4	Amateur	444.2000 N	156.7	449.2000 N	156.7	A	SnoCo ACS Auxiliary Repeater
	Repeater/DMR	TUL-L1	Amateur	442.3500 N	Local 1	447.3500 N	Local 1	D	Tulalip Local 1 (Anytone Only)
	Trunked	MSVL EOC	City Staff					D	Marysville EOC Talkgroup
	Trunked	EOC HAIL	City Staff					D	SnoCo EOC Calling Talkgroup

The convention calls for frequency lists to show four digits after the decimal place, followed by either an “N” or a “W”, depending on whether the frequency is narrow or wide band. Mode refers to either “A” or “D” indicating analog or digital (e.g. Project 25) or "M" indicating mixed mode. All channels are shown as if programmed in a control station, mobile or portable radio. Repeater and base stations must be programmed with the Rx and Tx reversed.